

MTR2 Operating

Menu	1st	2nd	3rd	4th	
Fn	Freq-readout 4digit	Speed increase=dah decrease=dit	Key-mem n finish=Fn Mes1=T-Dn Mes2=T-Up Mes3=Fn Rit=>EM	digi-mode Exit=Fn	user-Pref Exit=Fn orRit morse on/off T-Up store state T-Dn

Split-mode		
Rit (hold)	in {R} out {dot} T-Dn T-Up	Fn change

Quick-select			
Fn then	Rit DFE 4digit	T-Down Tune-mode exit = Fn on=dit off=dah	T-Up Batt-Vol

Sending message			
Rit then	T-Dn Mes1	T-Up Mes2	Fn Mes3
Pause	Dit		
Stop	Dah		

Restorinf default values
Menu holding power sw on

Strait key mode
mono plag in power on